





## X-800 Series Inspections

www.billypugh.com

Excellence in offshore personnel safety





## **800 Series Daily Inspection**

Daily inspection of X-800 procedure (by \*\*\*Qualified Person)

Serial #: Date of Inspection:			
Work Order #: Signature of Qualified Person:			
	Г		I
		Satisfactory	Non-Satisfactory
*Check for any damage or defect on all parts of the unit.			
Comments:			
*Visually inspect safety load lines, master links, safety sling and hardware.			
Comments:			
*Visually inspect crane hook positive locking device for function and physical conditions.	al		
Comments:			
*Check sidewall rigging, top & bottom platforms, and cushion ring for wear or damage.	-		
Comments:			
* Ensure snag resistant tag line is properly affixed.			
Comments:			

\*\*\*If any load bearing area of the 800 Series is worn or defective in any way, take the unit out of service immediately.

\*\*\*We recommend a JSA be completed before personnel transfer operations commence.

\*\*\*API definition of "Qualified Person" – A person designated by the employer who has the experience and training to safety operate the crane, rigging, and lifting devices assigned at the work location.

	Notes:
8	
dus Pec Co, Isc.	
Bred Co., Inc. 1990/// Billy Puch Co., Inc.	



## **800 Series** Quarterly Inspection

Quarterly inspection of X-800 procedure (by \*\*\*Qualified Inspector)

Serial #: Date of Inspection:		
Work Order #: Signature of Qualified Inspector:		
	Satisfactory	Non-Satisfactory
*Check for any damage or defect on all parts of the unit.		
Comments:		
		I
*Inspect top and bottom lifting ring for excessive wear, cracks, or corrosion following manufacturer's recommendation and relevant API spec.		
Comments:		
*Visually inspect safety load lines when attaching to crane. Inspect crane hook positive locking device for function and physical condition. Pinch fibers of rope, if fibers pull out, take the personnel net out of service.		
Comments:		
*Check sidewall rigging line splices (top & bottom) for wear, UV degradation (blistering, discoloration, or cracking), and unraveling. All synthetic rope splices should have a 3 tuck minimum.		
Comments:		

(361) 884-9351

CORPUS CHRISTI, TEXAS

INSPECTIONS